

Stanalog, Inc.
P. O. Box 671
Hagaman NY 12086
Tel: 518/843-3070
Fax: 518/843-8882
www.stanalog.com

Well Tempered Lab

Instructions for Well Tempered Lab Protractor

1. Place protractor over spindle. Mount cartridge in arm with approximate alignment
2. Move protractor and tonearm so that stylus tip is on inner bold-faced “+”
3. Adjust protractor and cartridge so that cartridge sides are parallel to the “+”
4. Repeat process for the outer bold-faced “+” (Rotate platter to line up stylus with each of the two cross points)
5. The stylus tip error at inner “+” should be slightly less than the parallel error at the outer “+”