

CONFIDENTIAL PARTS PRICE LIST

PLEASE READ CAREFULLY: This parts list is solely for the use of authorized Fisher service personnel, factory service stations, and franchised Fisher dealers. Prices do not include shipping charges.

Please include the serial number of the Fisher equipment for which the part(s) are intended. Send your order to

PARTS DEPARTMENT, FISHER RADIO, 11-40 45th Road, Long Island City, N.Y. 11101.



CHASSIS ASSEMBLY

CAPACITORS

Symbol	Description	Part No.	Net	Sug. Ret.
C126,226	Mylar, 0.056uF	TP4054B-1676	.20	.40
C10	Oil, 0.022uF, 450V	TP4054B-1801	.30	.60

RESISTORS

Composition in ohms, 5%, 1/4 watt, unless otherwise noted.
K = Kilohms, M = Megohms.

Symbol	Description	Part No.	Net	Sug. Ret.
R101,201	100K	RC07BF-104J	.15	.30
R102,202	220	RC07BF-221J	.15	.30
VR101, 201	Variable, 10K, VOLUME	TP4054B-3041	1.40	2.80

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
M3	Level Meter	TP4054B-3039	3.50	7.00
—	Meter Cushion	TP4054B-3054	.20	.40
—	Control Chassis	TP4054B-3049	.40	.80
SW4,7	Rocker Switch	TP4054B-3037	.40	.80
—	Switch Stud	TP4054B-3053	.15	.30
J101,201	Mold Jack, 4P (MIC)	TP4054B-3083	.50	1.00
—	Jack Nut	TP4054B-1517	.15	.30
T1	Power Transformer	TP4054B-3511	1.15	2.30
—	Trans Shield Plate	TP4054B-3635	.20	.40
—	Trans Shield Chassis	TP4054B-3082	.30	.60
M6	3P Terminal	TP4054B-3509	.30	.60
—	3P Terminal Insulation Plate	TP4054B-3510	.15	.30
—	Rubber Bushing	TP4054B-1431	.15	.30
M4,5	Lamp, 12V, 25mA	TP4054B-3031	.50	1.00
—	Side Plate (L)	TP4054B-3506	.45	.90
—	Side Plate (R)	TP4054B-3505	.45	.90
—	Socket Holder	TP4054B-3507	.25	.50
J102,202, 103,203	4P Jack	TP4054B-3038	.45	.90
—	Cord Stopper	TP4054B-4021	.15	.30
M7	Power Cord	TP4054B-1197	.45	.90
—	Main PCB Shield Plate	TP4054B-3512	.20	.40
—	Screw M2.6mm x 6mm Phil. Pan Head	TP4054E121	—	—
—	Washer, 2.6mm	TP4054E142	—	—
—	14P Connector	TP4054B-1709	.15	.30
—	14P Connector Sub P.C.B.	TP4054B-1660	.15	.30
—	14P Spacer	TP4054B-1774	1.10	2.20
—	Power Supply P.C.B. Ass'y	TP4054BA-3510	4.00	8.00
—	Deck Button G	TP4054C-3598	.15	.30
—	Pushbutton	TP4054C-3593	.15	.30

MISCELLANEOUS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
—	Control Chassis Ass'y	TP4054BA-3511	19.60	39.20
—	Main P.C.B. (R/P Amp) Ass'y	TP4054BA-3512	31.10	62.20
—	Mech. Chassis Ass'y	TP4054BA-3513	50.30	100.60
—	Screw M3mm x 6mm Phil. Round Head	TP4054E509	—	—
—	Screw M3mm x 5mm Flat Head	TP4054E533	—	—
—	Screw M3mm x 10mm Phil. Round Head	TP4054E503	—	—
—	3mm Toothed Washer	TP4054E172	—	—
—	M3mm Nut	TP4054E507	—	—
—	3mm Washer	TP4054E183	—	—

NOTE: For identification of mechanical parts, refer to RC-75 Cassette Recorder Service Manual.

TRANSPORT ASSEMBLY

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
—	Chassis Ass'y	TP4054CA-3101	4.40	8.80
—	Brake Ass'y	TP4054CA-3104	.30	.60
SW3	Mute Switch Ass'y	TP4054C-3107	.80	1.60
—	Head Base Guide Roller	TP4054C-3504	.15	.30
—	Head Base Ass'y	TP4054CA-3102	1.10	2.20
—	Head Base	TP4054C-3503	.30	.60
—	Pressure Roller Ass'y	TP4054CA-3105	.60	1.20
—	E Ring E-1.5mm	TP4054E45	—	—
—	Record/Playback Head Ass'y	TP4054CA-3096	7.70	15.40
—	Head Spring	TP4054C-3340	.05	.10
—	R.H. Holder	TP4054C-3309	.05	.10
M1	Record/Playback Head	TP4054C-3329	7.10	14.20
—	Screw M2mm x 4mm Pan Head	TP4054E124	—	—
—	Screw M2mm x 10mm Phil. Pan Head	TP4054E116	—	—
—	Erase Head Ass'y	TP4054CA-3068	3.90	7.80
—	E.H. Holder	TP4054C-3271	.10	.20
M2	Erase Head	TP4054C-3031	3.50	7.00
—	Cord Stopper	TP4054C-3591	.05	.10
—	Screw M2mm x 6mm Pan Head	TP4054E217	—	—
—	3mm Steel Ball	TP4054C-3595	.05	.10
—	Ball Retainer Spring	TP4054C-3513	.10	.20
—	Cassette Case Spring	TP4054C-3564	.10	.20
—	Cassette Guide	TP4054C-3544	.10	.20
—	Cassette Case Holder R Ass'y	TP4054CA-3108	.40	.80
—	Cassette Case Holder L Ass'y	TP4054CA-3109	—	—
—	Head Base Return Spring	TP4054C-3562	.05	.10
—	Reel Hub Ass'y	TP4054CA-3103	1.60	3.20
—	Pulley C	TP4054C-3516	.15	.30
—	Reel Hub Felt	TP4054C-3519	.15	.10
—	Reel Hub Ring	TP4054C-3522	.10	.20
—	Pulley D	TP4054C-3517	.10	.20

The Fisher RC-75 Cassette Recorder

TRANSPORT ASSEMBLY

MISCELLANEOUS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
—	Reel Hub Spring	TP4054C-3520	.05	.10
—	Thrust Bearing	TP4054C-3521	.05	.10
—	Sprocket	TP4054C-3518	.05	.10
—	Cassette Case B	TP4054C-3586	1.10	2.20
—	Cassette Lid A-2	TP4054C-3606	.35	.70
—	Lid Spring R	TP4054C-3654	.15	.30
—	Lid Spring L	TP4054C-3653	.15	.30
—	Pushbutton Ass'y	TP4054CA-3114	2.20	4.40
—	E Ring E-3mm	TP4054E181	—	—
—	Lock Plate Spring A	TP4054C-3609	.05	.10
—	Screw M2.6mm x 5 mm Pan Head	TP4054E219	—	—
—	Record Switch Spring	TP4054C-3589	.10	.20
—	Rocker Arm	TP4054C-3647	.10	.20
—	F.R.P. Lever B	TP4054C-3646	.10	.20
—	Lever Spring B	TP4054C-3650	.05	.10
—	Rocker Arm Pipe	TP4054C-3648	.05	.10
—	2.6mm Flat Washer (2.6x7.5x0.5)	TP4054E142	—	—
SW5	Pause Switch Ass'y	TP4054CA-3128	1.00	2.00
—	Pause Switch	TP4054C-3594	.50	1.00
—	Pause Switch P.C.B.	TP4054C-3645	.15	.30
—	Pause Switch Linkage Ass'y	TP4054CA-3117	.40	.80
SW4	Motor (Start) Switch Ass'y	TP4054CA-3113	1.20	2.40
—	Switch Case	TP4054C-3576	.20	.40
—	Motor (Start) Switch P.C.B.	TP4054C-3643	.20	.40
—	Eject Spring	TP4054C-3552	.05	.10
—	Eject Arm Ass'y	TP4054CA-3118	1.00	2.00
—	Eject Lever	TP4054C-3549	.10	.20
—	Eject Bracket	TP4054C-3550	.10	.20
—	Eject Pin	TP4054C-3551	.05	.10
—	Eject Linkage Wire	TP4054C-3553	.05	.10
—	Idler Pulley Ass'y	TP4054CA-3116	1.00	2.00
—	Idler Pulley	TP4054C-3618	.25	.50
—	Driver Pulley Shaft	TP4054C-3534	.10	.20
—	Ground Spring B	TP4054C-3659	.05	.20
—	Arm Drive Pulley	TP4054C-3530	.20	.40
—	Drive Pulley	TP4054C-3623	.20	.40
—	Flange	TP4054C-3624	.05	.10
—	Capstan Flywheel Ass'y	TP4054CA-3115	1.40	2.80
—	Flywheel Holder Ass'y	TP4054CA-3119	.40	.80
—	Flywheel Holder	TP4054C-3528	.20	.40
—	P.C.B. Stopper	TP4054C-3590	.05	.10
—	Ball Plate	TP4054C-1344	.05	.10
—	Record Sensor	TP4054C-3545	.20	.40
—	Record Lock Shaft (Washer Type)	TP4054C-3546	.05	.10
—	Record Sensor Linkage	TP4054C-3548	.10	.20
—	Record Lock Lever B	TP4054C-3652	.05	.10
—	Record Lock Lever Spring	TP4054C-3561	.10	.20
—	Amp Stud	TP4054C-3197	.25	.50
—	P.C.B. Stud	TP4054C-3563	.20	.40

TRANSPORT ASSEMBLY

MISCELLANEOUS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
—	Driving Belt	TP4054C-3616	.30	.60
—	Motor Ass'y	TP4054CA-3100	7.40	14.80
M9	Motor	TP4054C-3535	5.10	10.20
—	Motor Shield Plate C	TP4054C-3250	.15	.30
—	Motor Bracket	TP4054C-3537	.25	.50
—	Motor Shield Plate C	TP4054C-3625	.15	.30
—	Screw M2.6mm x 6mm Pan Head	TP4054E121	—	—
—	Motor Pulley	TP4054C-3617	.30	.60
—	Screw M2mm x 3mm	TP4054E224	—	—
—	Hex Nut M2.6mm	TP4054E21	—	—
—	Motor Governor (1 Lot/1-1500 Units)	TP4054CA-3110	4.90	9.80
—	Motor Governor (2 Lot/From 1501 Unit)	TP4054CA-3121	4.90	9.80
—	Spring Stopper	TP4054C-3644	.05	.10
—	Silver Tape	TP4054M-3016	.05	.10
—	Screw M2.6mm x 6mm Phil. Ft	TP4054E228	—	—
—	Screw M2.6mm x 5mm Phil. Pan Head	TP4054E219	—	—
—	Screw M2.6mm x 4mm Pan Head	TP4054E226	—	—
—	Screw M2.6mm x 6mm Phil. Pan Head	TP4054E121	—	—
—	Screw M2mm x 10mm Flat Head	TP4054E223	—	—
—	Screw M2.6mm x 4mm Flat Head	TP4054E227	—	—
—	Screw M2mm x 6mm Phil. Pan Head	TP4054E217	—	—
—	M2mm Nut	TP4054E176	—	—
—	E Ring E-1.2mm	TP4054E165	—	—
—	1.6mm Washer	TP4054C-3613	—	—
—	E Ring E-2mm	TP4054E222	—	—
—	Washer 3mm	TP4054E172	—	—
—	Screw M2.6mm x 10mm Pan Head Ft	TP4054E229	—	—
—	Screw M2.6mm x 8mm Pan Head Ft	TP4054E231	—	—
—	Screw M2.6mm x 10mm Flat Head	TP4054E230	—	—
—	Screw M2mm x 4mm Pan Head	TP4054E124	—	—
—	Tape Counter Ass'y	TP4054CA-3131	2.30	4.60
—	Tape Counter	TP4054C-3634	1.60	3.20
—	Counter Plate	TP4054C-3335	.05	.10
—	Counter Pulley	TP4054C-3569	.20	.40
—	Screw M3mm x 6mm Pan Head	TP4054E509	—	—
—	Counter Belt D	TP4054C-3633	.30	.60

NOTE: For identification of mechanical parts, refer to RC-75 Cassette Recorder Service Manual.

CABINET ASSEMBLY

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
—	Cabinet Ass'y	TP4054HA-3509	4.30	8.60
—	Top Cabinet	TP4054A-3011	.80	1.60
—	Shield Felt	TP4054A-3022	.05	.10
—	Counter Cover	TP4054A-3014	.10	.20
—	Power Light Cover	TP4054A-3015	.05	.10
—	Record Light Cover	TP4054A-3016	.05	.10
—	Name Plate	TP4054M-3041	.20	.40
—	Control Panel	TP4054M-3063	.50	1.00
—	Bottom Cabinet Ass'y	TP4054HA-3510	1.20	2.40
—	Bottom Cabinet	TP4054A-3020	1.00	2.00

The Fisher RC-75 Cassette Recorder

CABINET ASSEMBLY

MISCELLANEOUS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
—	Serial No. Plate	TP4054M-3049	.20	.40
—	Washer Felt	TP4054H-1133	—	—
—	Level Control (M) Ass'y	TP4054HA-3511	.30	.60
—	Level Control Knob (M)	TP4054H-3015	.30	.60
—	Level Control Knob Plate (M)	TP4054M-3022	.15	.30
—	Level Control (L) Ass'y	TP4054HA-3512	.40	.80
—	Level Control Knob (L)	TP4054H-3013	.40	.80
—	Level Control Knob Plate (L)	TP4054H-3021	.15	.30
—	Rubber Foot	TP1681A-3021	.15	.30
—	Cabinet Nut	TP4054A-3031	.10	.20
—	Deck Button G	TP4054C-3598	.10	.20
—	AC Switch Plate 120V	TP4054M-3039	.10	.20
—	AC Switch Plate 220V	TP4054M-3040	.10	.20
—	3mm Toothed Washer	TP4054E172	—	—
—	Screw M3mm x 8mm Pan Head	TP4054E521	—	—
—	Screw M3mm x 4mm Pan Head	TP4054E522	—	—
—	Washer 3.5mm x 7mm x 0.5mm T	TP4054E183	—	—
—	Screw M3mm x 8mm Pan Head	TP4054E534	—	—

NOTE: For identification of mechanical parts, refer to RC-75 Cassette Recorder Service Manual.

MOTOR GOVERNOR TA TYPE

CAPACITORS

Symbol	Description	Part No.	Net	Sug. Ret.
C1	0.05uF, 20%, 50V	TP4054B98	.15	.30
C2	Electrolytic, 0.47uF, 25V	TP4054B-1376	.30	.60
C3	Electrolytic, 4.7uF, 16V	TP1681B-1389	.20	.40

RESISTORS

Composition in ohms, 5%, 1/4 watt, unless otherwise noted.
K = Kilohms, M = Megohms.

Symbol	Description	Part No.	Net	Sug. Ret.
R1,R8	3.3K	RC07BF-332J	.15	.30
R2	33	RC07BF-330J	.15	.30
R3	6.8, 1%	TP4054B-1705	.15	.30
R4	200, 1%	TP4054B-1784	.15	.30
R5	68	RC07BF-680J	.15	.30
R6	470	RC07BF-471J	.15	.30
R7	680, 1%	TP4054B-1583	.20	.40
VR1	Variable, 500	TP4054B-1708	.25	.50

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
X1	Transistor, 2SA496 (O)	TP4054B-1695	.90	1.80
X2	Transistor, 2SC458L	TP4054B-1666	.40	.80
D1	Diode, KB-269	TP4054B-1702	.25	.50
—	P.C.B.	TP4054C-3600	.20	.40

MOTOR GOVERNOR TC TYPE

CAPACITORS

Symbol	Description	Part No.	Net	Sug. Ret.
C1	0.05uF, 20%, 50V	TP4054B98	.15	.30
C2	Electrolytic, 0.47uF, 25V	TP4054B-1376	.30	.60
C3	Electrolytic, 4.7uF, 16V	TP1681B-1389	.20	.40

RESISTORS

Composition in ohms, 5%, 1/4 watt, unless otherwise noted.
K = Kilohms, M = Megohms.

Symbol	Description	Part No.	Net	Sug. Ret.
R1	4.7K	RC07BF-472J	.15	.30
R2	33	RC07BF-330J	.15	.30
R3	20.5, 1%	TP4054B-1821	.30	.60
R4	470, 1%	TP4054B-1707	.20	.40
R5	68	RC07BF-680J	.15	.30
R6	470	RC07BF-471J	.15	.30
R7	680, 1%	TP4054B-1583	.20	.40
R8	3.3K	RC07BF-332J	.15	.30
VR1	Variable, 500	TP4054B-1708	.25	.50

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
X1	Transistor, 2SA496 (O)	TP4054B-1695	.90	1.80
X2	Transistor, 2SB77 (C)	TP4054B26	.50	1.00
D1	Diode, KB-269	TP4054B-1702	.25	.50
—	P.C.B.	TP4054C-3638	.20	.40

POWER SUPPLY

CAPACITORS

Symbol	Description	Part No.	Net	Sug. Ret.
C1,9	Electrolytic, 1000uF, 18V	TP4054B-1673	.50	1.00

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
D1,2,3,4	Silicon Diode, VO6C	TP1681B-1501	.30	.60
—	P.C.B.	TP4054B-3040	.40	.80

R/P AMPLIFIER (MAIN P.C.B.)

CAPACITORS

Symbol	Description	Part No.	Net	Sug. Ret.
C2	Electrolytic, 470uF, 16V	TP1681B-1392	.30	.60
C4	Electrolytic, 100uF, 16V	TP4054B-1400	.25	.50
C5,105,205	Mylar, 0.1uF, 20%, 50V	TP1681B93	.20	.40
C6	Mylar, 0.068uF, 20%, 50V	TP4054B-1694	.20	.40
C7,118,218	Mylar, 0.02uF, 20%, 50V	TP1681B90	.15	.30

The Fisher RC-75 Cassette Recorder

R/P AMPLIFIER (MAIN P.C.B.)

CAPACITORS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
C8,101, 201,108, 208	Electrolytic, 10uF, 10V	TP4054B78	.15	.30
C102,202	Ceramic, 220pF, 20%, 50V	TP4054B-1289	.15	.30
C103,203, 104,204	Mylar, 0.01uF, 20%, 50V	TP1681B95	.15	.30
C106,206	Ceramic, 47pF, 20%, 50V	TP4054B-1096	.20	.40
C107,207	Electrolytic, 100uF, 3V	TP4054B81	.15	.30
C109,209, 111,211, 116,216, 121,221	Electrolytic, 4.7uF, 16V	TP1681B-1389	.20	.40
C112,212, 119,219, 120,220	Mylar, 0.003uF, 20%, 50V	TP4054B-1156	.15	.30
C113,213	Mylar, 0.005uF, 20%, 50V	TP4054B94	.15	.30
C114,214	Mylar, 500pF, 20%, 50V	TP1681B96	.15	.30
C115,215	Mylar, 0.056uF, 20%, 50V	TP4054B-1676	.20	.40
C117,217	Ceramic, 330pF, 20%, 100V	TP4054B-1180	.20	.40
C123,223	Electrolytic, 10uF, 16V	TP4054B-1412	.20	.40
C124,224	Electrolytic, 330uF, 16V	TP4054B-1502	.25	.50
C125,225	Mylar, 0.0015uF, 10%, 50V	TP4054B-1711	.15	.30

RESISTORS

Composition in ohms, 5%, 1/4 watt, unless otherwise noted.
K = Kilohms, M = Megohms.

Symbol	Description	Part No.	Net	Sug. Ret.
R1,129, 229	220	RC07BF-221J	.15	.30
R3	Wirewound, 22	TP4054B-1440	.25	.50
R4	1	RC07BF-010J	.15	.30
R5	6.8, 1/2w	RC20BF-6R8J	.15	.30
R6,116, 216	1K	RC07BF-102J	.15	.30
R104,204	100	RC07BF-101J	.15	.30
R105,205, 106,206	100K, (N)	TP4054B-1334	.15	.30
R107,207	68, (N)	TP4054B-1453	.15	.30
R108,208, 125,225	3.3K	RC07BF-332J	.15	.30

RESISTORS (Cont.)

Symbol	Description	Part No.	Net	Sug. Ret.
R109,209, 122,222, 124,224, 131,231	22K	RC07BF-223J	.15	.30
R110,210, 121,221, 127,227	4.7K	RC07BF-472J	.15	.30
R111,211, 128,228, 130,230	1.5K	RC07BF-152J	.15	.30
R112,212	82K, (N)	TP4054B-1335	.15	.30
R113,213, 132,232	10K	RC07BF-103J	.15	.30
R114,214	150K	RC07BF-154J	.15	.30
R117,217, 123,223	100K	RC07BF-104J	.15	.30
R118,218	2.2K	RC07BF-222J	.15	.30
R119,219	12K	RC07BF-123J	.15	.30
VR102, 202	P.B. Level Adj, 50K	TP4054B-1176	.25	.50
VR103, 203	Record Level Adj, 10K	TP4054B-1505	.20	.40
V104,204	Meter Level Adj, 100K	TP4054B-1202	.25	.50
VR105, 205	Bias Current Adj, 20K	TP4054B-1436	.25	.50
VR106, 206	Record Current Adj, 10K	TP4054B-1505	.20	.40

NOTE: (N) denotes Low Noise Resistor

MISCELLANEOUS

Symbol	Description	Part No.	Net	Sug. Ret.
L1	Oscillator Coil	TP4054B-3508	.50	1.00
L101,201	Bias Trap Coil	TP4054B-1434	.40	.80
L102,202	Bias Trap Coil, 1.4mH	TP4054B-1352	.30	.60
—	Main P.C.B.	TP4054B-3501	2.20	4.40
—	Record Switch	TP4054B-3033	1.00	2.00
X101,201	Transistor, 2SC458LG (B), (C)	TP1681B-1421	.50	1.00
X102,202	Transistor, 2SC458LG (D)	TP1681B-1433	.50	1.00
X103,203, 104,204	Transistor, 2SC458L (C)	TP4054B-1666 (C)	.40	.80
X105,205	Transistor, 2SC735 (O), (Y)	TP1681B-1338	.50	1.00
D101,201	Diode, 1N60	TP1681B30P	.20	.40

BECAUSE ITS PRODUCTS ARE SUBJECT TO CONTINUOUS IMPROVEMENT, FISHER RADIO RESERVES THE RIGHT TO MODIFY ANY DESIGN OR SPECIFICATION WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION.

PRICES SUBJECT TO CHANGE WITHOUT NOTICE



FISHER RADIO • 11-40 45th ROAD • LONG ISLAND CITY • NEW YORK 11101