




QUADRAPHONIC AMPLIFIER


QA-800A

FVW KLW


Volume ass'y AWX-001




Volume ass'y AWX-001




R ass'y AWX-005




R ass'y AWP-005







Head amp ass'y W15-032




AWG-001




Control amp ass'y AWG-001




Main amp ass'y AWH-002




Main amp ass'y AWH-002




AWM-031





Decoder ass'y AWM-031







Logic ass'y AWM-032






Power supply ass'y AWR-018







Switch ass'y AWS-002



Switch ass'y AWS-003



Switch ass'y AWS-003



QA-800A

