



QUADRALIZER AMPLIFIER

QL-600A


FVW KLW


Input and output ass'y AWM-026







Control amp ass'y AWG-009






Power amp ass'y AWH-005








QL-600A

VR₁ ~ VR₄ : PRISET VOLUMES
VR₅ : MASTER VOLUMES


SWITCHES

S₁ : MODE SELECTOR


1. 2CH STEREO
 2. MATRIX REGULAR
 3. MATRIX SQ
 4. DISCRETE
- S₂ : 4CH TAPE MONITOR OFF ON
S₃ : 2CH TAPE MONITOR OFF ON
S₄ : POWER SWITCH OFF ON




Input & output ass'y AWM-026




Meter amp ass'y AWM-020




Control amp ass'y AWG-009




Input & output ass'y AW M-026




Decoder ass'y AWM-031



Power amp ass'y AWH-005



Meter amp ass'y AWM-020



Power supply ass'y AWR-016

