


- |                 |  |                |
|-----------------|--|----------------|
| SWITCH POSITION |  | S-1            |
| 1               |  | INPUT SELECTOR |
| 2               |  | MAG (SHOWN)    |
| 3               |  | TAPE HD        |
| 4               |  | TUNER          |
| 5               |  | AUX            |
|                 |  | S-2            |
| 1               |  | MODE SELECTOR  |
| 2               |  | LEFT (SHOWN)   |
| 3               |  | RIGHT          |
| 4               |  | MONO           |
| 5               |  | STEREO REVERSE |



MODEL SA-60 MONARCH