



Jan, 2013

Subject: NP-S2000 Firmware Update ver. 3.00

Yamaha is pleased to offer this firmware update to ensure the best possible performance for your Yamaha NP-S2000 Network Player.

This firmware includes the following improvements.

1. Compatibility with the 192 kHz and 176.4kHz sampling frequency in FLAC format
2. Compatibility with the AIFF format
3. Improves operation stability

*Audio output at 192kHz and 176.4kHz is only available through analog connection.

*Some of NAS drive products may not work with this function properly due to network environment and or other devices that reside on the network.

The following pages contain the firmware update instructions for NP-S2000 Network Player. You can easily update the latest firmware through the Internet. In order to properly execute the update, read all instructions carefully.

CHECK THE UNIT'S CURRENT FIRMWARE VERSION TO SEE IF A FIRMWARE UPDATED IS NEEDED

On the remote control, press the **SETUP** button.

Using the **UP/DOWN** buttons, select "**3 Firmware Ver.**".

If the firmware version is **V3.00 or higher**, your network player is already up-to-date.

If not, follow the procedures on the next page to update your network player.

INTERNET CONNECTION REQUIRED

Your network player is connected to the Internet if you can receive Internet radio stations. (See owner's manual for details)

IMPORTANT NOTICE

Follow the instructions carefully and do not attempt any other procedures not specified in the instructions provided by Yamaha.

Improperly updated products may cause improper operation, and any parts or service required to restore proper operation will not be covered under the Yamaha Limited Warranty.

INTERNET CONNECTION REQUIRED

Your network player is connected to the Internet if you can receive Internet radio stations. (See owner's manual for details)

Instruction for Firmware Update**STEP 1 Power on and enter SETUP mode**

Press **SETUP** button on the remote control.

STEP 2 Start Update


Using the **UP/DOWN** buttons, select menu **"4 Firmware Update"** and press **ENTER** button.

When **"Firmware Update OK?"** appears on the display, select **"YES"** by pressing the **LEFT** button.

Press **ENTER** button to start update.



Update in progress.....

**note:**

DO NOT interrupt the power or press any buttons during the update. In case the power is accidentally cut off, the network player will restore original firmware. Perform the update procedure from STEP 1 again.

In case **"Firmware Update NG"** appeared during the update, check your network setting and retry the update procedure again. System will restore original firmware.

Update is completed when **"Update Done"** is displayed. Then, power off.

STEP 3 Confirm updated firmware version

Power on and press the **SETUP** button on the remote control and select **"3 FIRMWARE Ver."** using the **UP/DOWN** buttons. Confirm that the firmware version has been updated.

Congratulations!

You have completed the firmware update. Your network player is ready for normal use.