SCHEMATIC DIAGRAM - SCHEMA



NOTE

1) Ss-1 ~ Ss-9 SELECTOR SWITCH 1-LW, 2-MW, 3-FM, 4-PHONO, 5-AUX
2) Sp-1 ~ Sp-6 SPEAKER SWITCH 1-OFF, 2-A, 3-QUATRA, 4-B, 5-A+B
3) ALL RESISTANCE VALUES ARE INDICATED IN "OHM". K=10^3OHM, M=10^6OHM)
4) ALL CAPACITANCE VALUES ARE INDICATED IN "μF" (P=10^{-6}μF).
5) Sa-1 ~ Sa-5 LW-MW SELECTOR SWITCH (LW POSITION)