

SANSUI G-401, G-4500 SCHEMATIC DIAGRAM

- SWITCHES & CONTROLS**
- POWER/SPEAKERS SW-4 1, power off
 - F-2711 2, A
 - 3, off
 - 4, B
 - 5, A+B
- LOUDNESS**
- F-2712 1, off
 - 2, on
- FM/AM/TAPE**
- F-2707 1, off
 - 2, on
 - 3, FM
 - 4, AM
- MODE**
- F-2707 1, stereo
 - 2, mono
- TAPE INDICATOR**
- SW-5a 1, source
 - 2, tape
- SELECTOR**
- SW-4a 1, aux
 - 2, phono
 - 3, FM
 - 4, AM

- RESISTORS**
- Are in ohms, % Wates ± 5% tolerance unless otherwise noted. K, M, W: K, M, W.
- CAPACITORS**
- Are in µF, unless otherwise noted. P, P-F.
- TOLERANCE**
- J: ±5% G: ±2% F: ±1%
- Each DC voltage shows the nominal value in volts at no input signal.

- SYMBOL**
- △ Ceramic
 - Mylar
 - Styrol
 - ⊠ Aluminum Electrolytic
 - (BP) Bi-polar Electrolytic
 - Low-leak Electrolytic
 - Fusing Resistor
 - ⊞ Non-thermizable Resistor

Each DC voltage shows the nominal value in volts at no input signal.



